

fi-5110C, fi-5110EOX, fi-5110EOX2, fi-5110EOXM, S500 & S500M

PRINTED CIRCUIT ASSEMBLIES

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
PA03360-K251		CONTROL PCA	-	X	X	-	-	-
PA03360-K261		ANALOG PCA	-	X	X	-	-	-
PA03360-K266		ANALOG PCA	-	-	-	X	-	-
PA03360-K281		PANEL PCA	-	-	-	X	-	-
PA03360-K291		CONTROL PCA	-	-	-	X	-	-
PA03360-K801	PA03360-K806	CONTROL PCA	X	-	-	-	-	-
PA03360-K811	PA03360-K816	ANALOG PCA	X	-	-	-	-	-
PA03360-K821	PA03360-K826	PANEL PCA	X	-	-	-	-	-
PA03360-K901		CONTROL PCA	-	X	-	-	-	-
PA03360-K911		ANALOG PCA	-	X	-	-	-	-
PA03360-K921		PANEL PCA	-	X	-	-	-	-
PA03360-K925		PANEL PCA	-	-	X	-	-	-
PA03360-K980		PANEL PCA	-	-	-	-	X	X
PA03360-K982		CONTROL PCA	-	-	-	-	X	-
PA03360-K983		ANALOG PCA	-	-	-	-	X	X
PA03360-K986		CONTROL PCA	-	-	-	-	-	X
PA03950-0093	PA03950-0223	INVERTER	X	X	X	-	-	-
PA03950-0223		INVERTER	-	-	-	X	X	X

ASSEMBLIES

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
PA03360-D811	PA03360-D816	UPPER UNIT	X	-	-	-	-	-
PA03360-D821	PA03360-D826	FIXED UNIT	X	-	-	-	-	-
PA03360-D912		REVOLVE UNIT	-	X	-	-	-	-
PA03360-D914		REVOLVE UNIT	-	-	-	X	-	-
PA03360-D916		REVOLVE UNIT	-	-	X	-	-	-
PA03360-D921		FIXED UNIT	-	X	X	-	-	-
PA03360-D926		FIXED UNIT	-	-	-	X	-	-
PA03360-D970		REVOLVE UNIT	-	-	-	-	-	X
PA03360-D980		REVOLVE UNIT	-	-	-	-	X	-
PA03360-D981		FIXED UNIT	-	-	-	-	X	-
PA03360-D981		FIXED UNIT	-	-	-	-	-	X
PA03360-E811		TOP COVER ASSY	X	-	-	-	-	-
PA03360-E821		CHUTE ASSY	X	-	-	-	-	-
PA03360-E841		GUIDE A ASSY	X	-	-	-	-	-
PA03360-E851		GUIDE P ASSY	X	-	-	-	-	-
PA03360-E891		STACKER ASSY	X	-	-	-	-	-
PA03360-E901		OPTICAL UNIT	-	X	X	-	-	-
PA03360-E905		OPTICAL UNIT	-	-	-	X	X	-
PA03360-E908	PA03360-E905	OPTICAL UNIT	X	-	-	-	-	-
PA03360-E912		TOP COVER ASSY	-	X	-	-	-	-
PA03360-E914		TOP COVER ASSY	-	-	-	X	-	-
PA03360-E916		TOP COVER ASSY	-	-	X	-	-	-
PA03360-E921		CHUTE ASSY	-	X	-	-	-	-
PA03360-E922		CHUTE ASSY	-	-	X	-	-	-
PA03360-E924		CHUTE ASSY	-	-	-	X	-	-
PA03360-E932		BASE COVER ASSY	-	X	-	-	-	-
PA03360-E934		BASE COVER ASSY	-	-	-	X	-	-
PA03360-E942		GUIDE A ASSY	-	X	X	-	-	-
PA03360-E944		GUIDE A ASSY	-	-	-	X	-	-
PA03360-E951		GUIDE P ASSY	-	X	X	-	-	-
PA03360-E955		GUIDE P ASSY	-	-	-	X	-	-
PA03360-E970		TOP COVER ASSY	-	-	-	-	-	X
PA03360-E971		GUIDE P ASSY	-	-	-	-	-	X
PA03360-E972		GUIDE A ASSY	-	-	-	-	-	X
PA03360-E973		CHUTE ASSY	-	-	-	-	-	X
PA03360-E974		STACKER ASSY	-	-	-	-	-	X
PA03360-E976		LID COVER ASSY	-	-	-	-	-	X

fi-5110C, fi-5110EOX, fi-5110EOX2, fi-5110EOXM, S500 & S500M

ASSEMBLIES (CONTINUED)

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
PA03360-E980		TOP COVER ASSY	-	-	-	-	X	-
PA03360-E981		GUIDE P ASSY	-	-	-	-	X	-
PA03360-E982		GUIDE A ASSY	-	-	-	-	X	-
PA03360-E983		CHUTE ASSY	-	-	-	-	X	-
PA03360-E984		STACKER ASSY	-	-	-	-	X	-
PA03360-E986		LID COVER ASSY	-	-	-	-	X	-
PA03360-E992		STACKER ASSY	-	X	X	-	-	-
PA03360-E994		STACKER ASSY	-	-	-	X	-	-
PA03360-F911	PA03360-F916	SENSOR ASSY B	X	X	X	-	-	-
PA03360-F916		SENSOR ASSY B	-	-	-	X	-	-
PA03360-F917		SENSOR ASSY B2	-	-	-	-	X	-
PA03360-F917		SENSOR ASSY B2	-	-	-	-	X	X
PA03360-K931		AC ADAPTER	-	X	X	-	-	-
PA03360-K934		AC ADAPTER	-	-	-	X	-	-
PA03360-K936		AC ADAPTER	X	-	-	-	X	X
PA03360-K940	PA03360-K946	LAMP	X	X	X	-	-	-
PA03360-K946		LAMP	-	-	-	X	X	X
PA03360-K951		REV FRAME ASSY	X	X	X	X	X	X
PA03360-K952		FIX FRAME ASSY	X	X	X	X	-	-
PA03360-K984		FIX FRAME ASSY	-	-	-	-	X	X
PA03360-Y260		CARRIER SHEET	-	-	X	-	X	-
PA03360-Y721		SIDE COVER L	-	-	-	-	X	-
PA03360-Y725		SIDE COVER L	-	-	-	-	-	X
PA03360-Y731		SIDE COVER R	-	-	-	-	X	-
PA03360-Y735		SIDE COVER R	-	-	-	-	-	X
PA03950-0085		MOTOR	X	X	X	X	-	-
PA03950-0096		EMPTY SENSOR	X	-	-	-	-	-
PA03950-K981		MOTOR	-	-	-	-	X	X
PA03951-0305		SENSOR PTR	X	-	-	-	-	-
PA03951-0306		SENSOR LED	X	-	-	-	-	-
PA61001-0141	PA61001-0142	USB CABLE	X	X	X	-	-	-
PA61001-0155		USB CABLE	-	-	-	X	-	X
PA61001-0159		USB CABLE	-	-	-	-	X	-
PA63088-2001		AC CABLE U	X	X	X	-	X	X
PA63089-2001		AC CABLE U	-	-	-	X	-	-
PA63090-2001		AC CABLE E	-	-	-	X	-	X

PIECE PARTS

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
PA03289-Y005		PANEL COVER	X	-	-	-	-	-
PA03289-Y333		PAD PLATE BASE	-	-	-	-	X	X
PA03360-K941		HK RING	X	X	X	X	X	X
PA03360-K985		LID ASSY	-	-	-	-	X	-
PA03360-K989		LID ASSY	-	-	-	-	-	X
PA03360-Y002		PINCH ROLLER	X	X	X	X	X	X
PA03360-Y015		PAD SPRING	X	X	X	X	-	-
PA03360-Y016		J-SHEET	X	X	X	X	X	X
PA03360-Y017		PAD PLATE	X	X	X	X	-	-
PA03360-Y050		PAD PLATE M	-	-	-	-	X	X
PA03360-Y051		PAD SPRING M	-	-	-	-	X	X
PA03360-Y101		FEED ROLLER	X	X	X	X	X	X
PA03360-Y102		PULLEY GEAR	X	X	X	X	-	-
PA03360-Y103		PULLEY M	X	X	X	X	X	X
PA03360-Y104		GEAR	X	X	X	X	X	X
PA03360-Y105		PICK GEAR	X	X	X	X	X	X
PA03360-Y106		CLUTCH SPRING	X	X	X	X	X	X
PA03360-Y107		CLUTCH	X	X	X	X	X	X
PA03360-Y108		IDLE PULLEY	X	X	X	X	X	X

fi-5110C, fi-5110EOX, fi-5110EOX2, fi-5110EOXM, S500 & S500M

PIECE PARTS (CONTINUED)

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
PA03360-Y110		PICK SHAFT	X	X	X	X	X	X
PA03360-Y112		PICK BEARING M	X	X	X	X	X	X
PA03360-Y113		BEARING M	X	X	X	X	X	X
PA03360-Y115		EXIT ROLLER	X	X	X	X	X	X
PA03360-Y133		W PULLEY	-	-	-	-	X	X
PA03360-Y134		IDLER S	-	-	-	-	X	X
PA03360-Y255		OG LABEL 2	-	-	X	-	-	-
PA03360-Y302		USB LID	-	X	X	-	-	-
PA03360-Y304		USB LID	-	-	-	X	-	-
PA03360-Y322		STACKER-2	-	X	X	-	-	-
PA03360-Y324		STACKER-2	-	-	-	X	-	-
PA03360-Y475		CHUTE SW	-	-	X	-	-	-
PA03360-Y476		SW SPRING	-	-	X	-	X	X
PA03360-Y480		NAME PLATE	-	X	-	-	-	-
PA03360-Y482		NAME PLATE2	-	-	X	-	-	-
PA03360-Y484		NAME PLATE	-	-	-	X	-	-
PA03360-Y750		LID SPRING L	-	-	-	-	X	X
PA03360-Y751		LID SPRING R	-	-	-	-	X	X
PA03360-Y752		SPRING COVER L	-	-	-	-	X	X
PA03360-Y753		SPRING COVER R	-	-	-	-	X	X
PA03360-Y921		STACKER EXTEND	-	-	-	-	X	-
PA03360-Y925		STACKER EXTEND	-	-	-	-	-	X
PA03360-Y981		CHUTER SW	-	-	-	-	X	-
PA03360-Y987		CHUTER SW	-	-	-	-	-	X
PA03950-0211		BELT S	-	-	-	-	X	X
PA03951-0314		BELT	X	X	X	X	X	X
PA49001-0377		COVER OPEN SENSOR	X	X	X	X	X	X
PA70002-2607		CCD HARNESS F	X	X	X	X	X	X
PA70002-2608		BS HARNESS	X	X	X	X	X	X
PA70002-2609		SE HARNESS F	X	X	X	X	X	X
PA70002-2610		FG HARNESS	X	X	X	X	X	X
PA83950-0330		RUBBER	X	X	X	X	X	X
PA83952-2636		PT SCREW	X	X	X	X	X	X
PA83952-4605		E-RING	-	-	-	-	X	X
PA83952-5038		PT SCREW	-	-	-	-	X	X
RU6ER3-S	PA83952-4605	E-RING	X	X	X	X	-	-
RU6SNA3-05121		SCREW	X	X	X	X	X	X
RU6SW3N3-08121		SCREW	X	X	X	X	X	X
RU6SW3N3-10121		SCREW	-	-	-	-	-	X
RU6WM3-111		WASHER	X	-	X	-	-	-
RU6WM3-121		WASHER	-	-	-	-	X	X
RU6WM5-121		WASHER	-	X	X	X	-	-

CONSUMABLES

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
CG01000-510501		SCANAID CONSUMABLE & CLEANING KIT	X	X	X	X	X	X
PA03360-0001		PICK ROLLER ASSEMBLY	X	X	X	X	X	X
PA03360-0002		PAD ASSEMBLY	X	X	X	X	X	X

fi-5110C, fi-5110EOX, fi-5110EOX2, fi-5110EOXM, S500 & S500M

CLEANING

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
CA99501-0012		CLEANING PAPER, 10 PACK	X	X	X	X	X	
CA99501-0013		F1 CLEANER	X	X	X	X	X	
CG00000-602701		CLEANING PAPER, 50 PACK	X	X	X	X	X	
CG01000-373001		CLEANING KIT	X	X	X	X	X	
CG90000-120001		CLEANING CLOTH, 20 PACK	X	X	X	X	X	
CG90000-120601		CLEANING SWABS, 100 BAG	X	X	X	X	X	

OPTIONS

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
PA03360-0011		SCANSNAP MANAGER & ORGANIZER UPGRADE KIT	-	X	-	-	-	
PA03360-0013		SCANSNAP CARRIER SHEET (5 PACK)	-	X	X	X	X	
PA03951-0651		SCANSNAP CARRYING CASE	-	X	X	X	X	

MANUALS

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
P3PC-1072		GETTING STARTED	X	-	-	-	-	-
P3PC-1082		OPERATOR'S GUIDE	X	-	-	-	-	-
P3PC-1402		GETTING STARTED	-	-	-	X	-	-
P3PC-1412		OPERATOR'S GUIDE	-	-	-	X	-	-
P3PC-1522		OPERATOR'S GUIDE	-	-	-	-	X	-
P3PC-1532		GETTING STARTED	-	-	-	-	X	-
P3PC-1742		GETTING STARTED	-	-	-	-	-	X
P3PC-1752		OPERATOR'S GUIDE	-	-	-	-	-	X
P3PC-E817		OPERATOR'S GUIDE	-	X	X	-	-	-
P3PC-E827		GETTING STARTED	-	X	X	-	-	-

PACKAGING

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
PA03209-Y398		HANDLE-SS	-	X	X	X	X	X
PA03209-Y399		HANDLE-BASE-SS	-	X	X	X	X	X
PA03360-K412		PACKAGE	-	-	-	-	X	-
PA03360-K431		PACKAGE	-	-	-	-	-	X
PA97300-K682		FULL PACKAGING MATERIAL	-	X	-	-	-	-
PA97300-K731		FULL PACKAGING MATERIAL	X	-	-	-	-	-
PA97300-K892		FULL PACKAGING MATERIAL	-	-	X	-	-	-
PA97301-K051		FULL PACKAGING MATERIAL	-	-	-	X	-	-
PA97301-Y244		CUSHION BL	-	X	X	X	-	-
PA97301-Y245		CUSHION BR	-	X	X	X	-	-
PA97301-Y247		CUSHION TL	-	X	X	X	-	-
PA97301-Y248		CUSHION TR	-	X	X	X	-	-
PA97301-Y257		OUTER BOX	X	-	-	-	-	-
PA97301-Y264		OUTER BOX	-	X	-	-	-	-
PA97301-Y271		CUSHION BL	X	-	-	-	-	-
PA97301-Y272		CUSHION BR	X	-	-	-	-	-
PA97301-Y273		CUSHION TL	X	-	-	-	-	-
PA97301-Y274		CUSHION TR	X	-	-	-	-	-
PA97301-Y680		OUTER BOX	-	-	X	-	-	-
PA97301-Y687		OUTER BOX	-	-	-	X	-	-
PA97301-Y980		OUTER BOX	-	-	-	-	X	-
PA97301-Y985		CUSHION BL	-	-	-	-	X	-
PA97301-Y985		CUSHION BL	-	-	-	-	-	X
PA97301-Y986		CUSHION BR	-	-	-	-	X	-
PA97301-Y986		CUSHION BR	-	-	-	-	-	X
PA97301-Y987		CUSHION TL	-	-	-	-	X	-

fi-5110C, fi-5110EOX, fi-5110EOX2, fi-5110EOXM, S500 & S500M

PACKAGING

PART NUMBER	RoHS PART NUMBER	DESCRIPTION	fi-5110C	fi-5110EOX	fi-5110EOX2	fi-5110EOXM	S500	S500M
PA97301-Y987		CUSHION TL	-	-	-	-	-	X
PA97301-Y988		CUSHION TR	-	-	-	-	X	-
PA97301-Y988		CUSHION TR	-	-	-	-	-	X
PA97302-Y151		OUTER BOX	-	-	-	-	-	X